



Engineering & Product Development Group

## 2012 SHAFT TIP TRIMMING INSTRUCTIONS

The tip trimming information below is to be used for preparation of the shaft before assembly. Following the tip trimming procedure, assemble the shaft into the head. Then butt trim the shaft to the desired playing length.

### Wood Shafts Parallel Tip Models

MODEL NUMBER	Driver	3W	5W	7W
1600, 1610, 1700, 1710, 1731, 1800, 1810, 1831, 1900, 1931, 2350, 2360, 2370, 2380, 2390				
3150L, 3150R, 4040, 4940, 5050, 5535, 5545, 5555, 6060, 6066, 6300R, 6300L, 6800, 6850, 6530, 6540, 6550, 6740, 7070, 7076, 7550, 7850, 7860, 7525, 7535, 7545, 7640, 8520, 8530, 8540, 8800, 9090, 9160, 9170, 9180, 9190, 9520, 9530	0	1	2	2
3340, 3350, 3360, 3370, 3380, 3390	0	0.5	1	1.5
5240, 5250, 5260, 5270, 5280				
3150A, 3150S, 6300S, 6300A	1	2	3	3
7500, 7950, 7960, 8200	N/A	0	1	2

For more information or answers to technical questions, please visit our website at [USTMamiya.com](http://USTMamiya.com) or contact the UST Mamiya Customer Service Department at:  
 1-800-621-6728 in the USA  
 Central Time  
 Mon. - Thurs. 7:30 a.m. until 5 p.m. Friday  
 7:30 a.m. until 2:30 p.m.

### Iron Shafts Parallel Tip Models

MODEL NUMBER	1 iron	2 iron	3 iron	4 iron	5 iron	6 iron	7 iron	8 iron	9 iron	P Wedge	S Wedge
350, 386											
454											
630R, 630L, 642	0	1/2	1	1 1/2	2	2 1/2	3	3 1/2	4	4	4
955											
630S, 630A	1	1 1/2	2	2 1/2	3	3 1/2	4	4 1/2	5	5	5
345M, 785L, 386L	N/A	N/A	0	1/2	1	1 1/2	2	2 1/2	3	3	3
140, 233, 980T, 990T	BUTT TRIM ONLY...NO TIP TRIM REQUIRED										

### Utility Shafts Parallel Tip Models

MODEL NUMBER	#1 Hybrid	#2 Hybrid	#3 Hybrid	#4 Hybrid	#5 Hybrid
102, 103, 104, 131, 199, 11320					
209, 231, 285,					
300, 375, 383, 386					
700, 710, 780, 788, 790	0	1/2	1	1 1/2	2
820, 852, 853, 854, 855, 870, 875					
7500, 8200, 8260					

Revision Date: 11.2.2011 jdp